




MOD : CCV5-MP

Production code : 30000033887

08/2026

EN

ASSEMBLY OF ICE-CREAM FREEZER GLASS




D 400 DFSG AF
D 500 DFSG AF

1. CONTENTS

1. Section : Content
2. Section : The final appearance of ice-cream freezer
3. Section : Required tools for mounting
4. Section : Mounting steps
 - a. Mounting of Al glass fastening profiles.
 - b. Mounting of enlightened glass support sheet and front glass
 - c. Mounting of Right-Left glass and mounted upper glass +enlightened glass support sheet
 - d. Mounting of front round glass
 - e. Connecting lighting cord and installing right-left side profile
 - f. Installing lexan group

2. The final appearance of ice-cream freezer

The final appearance of ice-cream freezer is shown in Picture-1 after the mounting of ice-cream freezer glass display is finished.




Picture 1

3. Required tools for mounting

1. Charged or electricity drill
2. 2,5mm drill bit
3. Charged screwdriver
4. Thin star bit + M6 Socket wrench
5. Transparent silicon (adhesive feature) and silicon gun
6. PVC band

Demounted figure of glass display is shown in picture-2.



Picture 2

NUMBER	PART NAME	QUANTITY
1	ICE-CREAM FREEZER	1
2	BODY FRAME	1
3	RIGHT GLASS AL PROFILE	1
4	LEFT GLASS AL PROFILE	1
5	FRONT GLASS AL PROFILE	1
6	SCREW 2.9-1.6 YHB	1-2
7	RIGHT-LEFT GLASS	2
8	BOLT M6*1.5 YSB+ PLASTIC BOLT BEARING	6+6
9	NUT M6 LOWER CORNER	6
10	RIGHT-LEFT GLASS SIDE PROFILE	2
11	FRONT CAMBER GLASS	1
12	ENLIGHTED GLASS SUPPORT SHEET	1
13	UPPER GLASS	1
14	BACK LEXAN GRIPPER	1
15	FRONT LEXAN GRIPPER	1
16	LEXAN TRANSPARENT	1
17	2.9*1.3 YSB SHEET SCREW	6